

NATURAL GROUND MOUNTING INSTRUCTIONS by FLEXPOST®

Tools Required:

- Post Hole Digger
- Tape Measure
- 3/4" Ratchet Wrench
- 3/4" Wrench
- Hammer

Parts Included:

- 1 - Natural Ground Anchor
- 1 - Post Lock
- 1 - 12" SS20 Post

1



- Identify desired mounting location.
- Use post hole digger to excavate hole.

2



- Hole depth should be around 24" in depth.

3



- Assemble signpost system before installation.

4



- 12" post should be slid into natural ground anchor first.
*Note: Insert end of post without hole.

5



- Next the post lock is slid over the top of the 12" post and down around top of natural ground anchor.
- Use hammer to secure post lock in place if needed.

6



- Attach spring to 12" post with aluminum hex bolt provided in kit.

7



- Place assembled natural ground anchor in ground and fill with dirt.
*Note: For a more permanent application fill hole with cement.

FLEXPOST

4190 Sunnyside Drive
Holland, MI 49424 USA
Phone (866) 577-2588 or (616) 928-0829
Fax (616) 928-1138

CAUTION: Check Underground Utilities Before Installing Natural Ground Anchor!